



Place the Mk 7 Power Tube in a cool place for half-an-hour and then push the piston rod into the tube so that it will be ready to be fitted. This will enable the unit to be set to start opening at the lower temperature, remembering to re-fit the unit in the closed position.

BAYLISS PRECISION COMPONENTS LTD
 LYSANDER WORKS, BLENHEIM ROAD, AIRFIELD INDUSTRIAL ESTATE
 ASHBOURNE, DERBYSHIRE DE6 1HA